

Exercise 18: Terrain Analysis

Raster analysis has been explored in previous exercises. Here, we will focus specifically on terrain analysis using digital elevation models (DEMs). This exercise describes how to produce a variety of terrain derivatives from DEMs. The processes outlined here make use of a variety of raster analysis tools and techniques. In the last part of the lab, you will produce a cut and fill model by differencing two DEMs.

The DEM that will be used at the beginning of this exercise covers a portion of Preston County, West Virginia. It was derived from light detection and ranging (LiDAR) data at a 5 m spatial resolution. The raw LiDAR data are available here: <http://tagis.dep.wv.gov/home/?q=Downloads>. They can also be obtained from West Virginia View: <http://www.wvgis.wvu.edu/lidar/>. A later lab exercise will show how to process raw LiDAR data. It should be noted that these data will support the creation of a 1 m resolution DEM; however, a 5 m DEM will be used in this lab to reduce file size and processing time. For the last part of the lab, two separate DEMs will be used. They were also both generated from LiDAR data. As surface mining occurred between the collections of these datasets, the extent of elevation or terrain change can be assessed by differencing these surfaces.

Topics covered in this exercise include:

1. Create slope, aspect, and hillshade raster grids from a DEM.
2. Create and interpret surface curvature grids.
3. Use neighborhood analysis and raster math to produce more complex terrain outputs.
4. Difference two DEMs to obtain cut and fill extents.

Step 1. Open a Map Project

First, we need to download and open the **Exercise_18.aprx** file.

- ☐ Download the **Exercise_18** data from <https://www.wvview.org/>. All lab materials are available on the course webpage and linked to the exercise. You will need to extract the compressed files and save it to the location of your choosing.
- ☐ Open ArcGIS Pro. This can be done by navigating to All Apps followed by the ArcGIS Folder. Within the ArcGIS Folder, select ArcGIS Pro.

Note that you can also use a Task Bar or Desktop shortcut if they are available on your machine.


- ❑ After ArcGIS Pro launches, select “Open another project.”



- ❑ Navigate to the directory that houses the material for this course. The project files are in the **Exercise_18** folder where it was saved on your local machine.
- ❑ Select **Exercise_18.aprx**. Click OK to open the project.
- ❑ If necessary, navigate to the WV map.

Note: If you’d prefer, you can also just click on the **Exercise_18.aprx** file within the uncompressed folder directly to launch ArcGIS Pro.

This project should contain two maps that house the data needed for the lab: Part1 and Part2. You will start with the Part1 map.




Step 2. Defining Environment Settings

Since you will perform many spatial analysis operations in this lab, you will start by setting the environment settings. It is generally a good idea to set environment settings any time you will perform spatial analysis operations in

a project. Also, this can speed up your processing, as you will not need to set environments for each tool individually.

- ☐ Make sure the Part1 map is active.
- ☐ Navigate to the Analysis Tab then select Environments in the Geoprocessing Area.
- ☐ Check and change (if needed) the Current Workspace and the Scratch Workspace to the **Exercise_18.gdb** geodatabase in the **Exercise_18** folder. This will cause all the outputs to automatically be saved to this location.
- ☐ Set the Output Coordinate System to Current Map [Part1] (should be NAD 1983 UTM Zone 17 North) under Output Coordinates.
- ☐ Set the processing extent to be the same as the **dem** layer under Processing Extent.
- ☐ Also under Raster Analysis, set the Snap Raster to the **dem** layer.
- ☐ Set the cell size to be the same as the **dem** layer (should be 5, meaning 5 by 5 meters) under Raster Analysis.
- ☐ Also under Raster Analysis, set the Mask to the **dem** layer.
- ☐ Click OK to accept these settings.


A screenshot of the "Environments" dialog box in ArcGIS. The dialog has a search bar at the top. It is divided into several sections: "Workspace" with fields for "Current Workspace" and "Scratch Workspace", both set to "Exercise_18.gdb"; "Output Coordinates" with "Output Coordinate System" set to "NAD_1983_UTM_Zone_17N" and "Geographic Transformations" set to an empty dropdown; "Processing Extent" with "Extent" set to a selection tool icon, and "X and Y Extent" fields for Top (4366038.32164722), Left (610080.96539675), Right (626275.96539675), and Bottom (4354183.32164722); "Extent Coordinate System" set to "NAD 1983 UTM Zone 17N"; and "Parallel Processing" with "Recycle Interval Of Processing" set to an empty field. At the bottom are "OK" and "Cancel" buttons.

Note: Setting the snap raster to the **dem** layer means that all the raster grids you create will align perfectly with the original. We recommend setting a snap raster, especially if you plan to perform any raster overlay, as you will do here, since this results in a cleaner overlay, as the cells align perfectly.


Step 3. Create Topographic Slope, Topographic Aspect, and Hillshade Grids

First, you will create topographic slope, aspect, and hillshade grids from the DEM data. You will begin with slope.

Note: In this lab, we will access tools from ArcToolbox. However, there are many ways to access tools in ArcGIS Pro. For example, the more common tools are provided in the Tools list in the Analysis Tab.




Once you select the Tools button in the Analysis tab, it will open the Geoprocessing Pane.



We have decided to demonstrate ArcToolbox here so that you get a sense of where the tools are in the Toolbox directory. You can also create your own tools and toolboxes, which will be investigated in later labs.

- ☐ In the Analysis Tab, select Tools from the Geoprocessing Area. This should open the Geoprocessing Pane.
- ☐ In the Geoprocessing Pane, navigate to Toolboxes.




Favorites | **Toolboxes** | Portal

Note: We will not provide these directions for accessing other tools. We will just tell you where to find them within ArcToolbox.

- ☐ Navigate to Spatial Analyst Tools followed by the Surface sub toolbox.



- ☐ Click on the **Slope Tool**.
- ☐ Set the Input Raster to the **dem** layer.
- ☐ Name the Output Raster **slope** (this will save to the **Exercise_18.gdb** geodatabase, as defined in the environment settings).
- ☐ Make sure the Output Measurement is set to "Degrees."
- ☐ Make sure the Method is set to "Planar."
- ☐ Make sure the Z Factor is set to 1.
- ☐ Click Run to execute the tool. The output should automatically be added to your map.



Question 1. What is the difference between topographic slope measurements made in degrees vs. percent rise? (4 Points)

Now, you will create a topographic aspect grid.

- ☐ Navigate to Spatial Analyst Tools followed by the Surface sub toolbox.
- ☐ Click on the **Aspect Tool**.
- ☐ Set the Input Raster to the **dem** layer.
- ☐ Name the Output Raster **aspect**.
- ☐ Make sure the Method is set to "Planar."
- ☐ Click Run to execute the tool. The output should automatically be added to your map.




Question 2. In the default legend generated for the aspect grid, what azimuth range is defined as southeast? (2 Points)

Question 3. In the default legend generated for the aspect grid, what is the default color used to symbolize flat areas? (2 Points)

Now, you will create a hillshade.

- ☐ Navigate to Spatial Analyst Tools followed by the Surface sub toolbox.
- ☐ Click on the **Hillshade Tool**.
- ☐ Set the Input Raster to the **dem** layer.
- ☐ Name the Output Raster **hillshade**.
- ☐ Leave the Azimuth set to 315 and the Altitude set to 45.
- ☐ You do not need to change any additional settings.
- ☐ Click Run to execute the tool. The output should automatically be added to your map.



Note: Hillshade images are useful for displaying elevation data. They are much more visually appealing than a DEM.

Question 4. Explain what the azimuth option defines. (4 Points)


Question 5. Explain what the altitude option defines. (4 Points)

Feel free to experiment with the azimuth and altitude options to determine how they impact the resulting hillshade surface.

Step 4. Create Curvature Grids

You will now create curvature grids for curvature, profile curvature, and plan curvature.

- ☐ Navigate to Spatial Analyst Tools followed by the Surface sub toolbox.
- ☐ Click on the **Curvature Tool**.
- ☐ Set the Input Raster to the **dem** layer.
- ☐ Name the Output Curvature Raster **curve**.
- ☐ Name the Output Profile Curvature Raster **pro_curve**.
- ☐ Name the Output Plan Curvature Raster **plan_curve**.
- ☐ You do not need to change any additional settings.
- ☐ Click Run to execute the tool. The output should automatically be added to your map.



Note: If you do not define an output for the profile and plan curvature, only the curvature raster will be generated.

Note: Positive values indicate convex surfaces while negative surfaces indicate concave surfaces. Values near zero indicate flat surfaces.

Question 6. Explain the concept of profile curvature. (4 Points)


Question 7. Explain the concept of plan curvature. (4 Points)

Step 5. Create a Slope Position Raster Grid

You will now learn to create more complex terrain derivatives using the **Raster Calculator Tool** and neighborhood analysis. We will begin with slope position, which provides a measure of slope position from the valley bottom to the ridge. Note that this measure is dependent on the window size specified.

You will start by finding the mean elevation value within a circular radius of 9 cells around each cell.



- ☐ Navigate to Spatial Analyst Tools followed by the Neighborhood sub toolbox.
- ☐ Click on the **Focal Statistics Tool**.
- ☐ Set the Input Raster to the **dem** layer.
- ☐ Name the Output Raster **mean**.
- ☐ Define the Neighborhood using a "Circle" with a radius of 9 cells.
- ☐ Make sure the Statistic Type is set to "Mean."
- ☐ You do not need to change any additional settings.
- ☐ Click Run to execute the tool. The output should automatically be added to your map.



You now want to compare the original elevation at the cell to the mean value calculated above to determine if the elevation is higher or lower than the

mean of the neighborhood. You will do this using the **Raster Calculator Tool**.

- ☐ Navigate to Spatial Analyst Tools followed by the Map Algebra sub toolbox.
- ☐ Click on the **Raster Calculator Tool**.
- ☐ Define the syntax as follows: "dem" - "mean".
- ☐ Name the Output Raster **sp**.
- ☐ You do not need to change any additional settings.
- ☐ Click Run to execute the tool. The output should automatically be added to your map.



Examine your slope position output to answer the following question. It might help to compare it with the hillshade image.


Question 8. In terms of slope position, what topographic positions are associated with high slope position values? (4 Points)

Step 6. Create a Terrain Roughness Raster Grid

You will now create a terrain roughness raster, which provides a measure of how variable or rugged the terrain is based on how variable the elevation measurements are in a given window size. Note that this measure is dependent on the window size specified.


You will begin by calculating the standard deviation in a circular radius of 9 cells around each cell.

- ☐ Navigate to Spatial Analyst Tools followed by the Neighborhood sub toolbox.
- ☐ Click on the **Focal Statistics Tool**.
- ☐ Set the Input Raster to the **dem** layer.
- ☐ Name the Output Raster **sd**.
- ☐ Define the Neighborhood using a "Circle" with a radius of 9 cells.
- ☐ Make sure the Statistic Type is set to "Standard deviation."
- ☐ You do not need to change any additional settings.
- ☐ Click Run to execute the tool. The output should automatically be added to your map.




You will now use raster math to calculate the square root of the standard deviation surface produced above.

- ☐ Navigate to Spatial Analyst Tools followed by the Map Algebra sub toolbox.
- ☐ Click on the **Raster Calculator Tool**.
- ☐ Define the syntax as follows: SquareRoot("sd"). Note that the square root operator is available from the Tools list.
- ☐ Name the Output Raster **roughness**.
- ☐ You do not need to change any additional settings.
- ☐ Click Run to execute the tool. The output should automatically be added to your map.



Examine your roughness output to answer the following question. It might help to compare it with the hillshade image.

Question 9. In terms of roughness, what do high values indicate? (4 Points)




Step 7. Create a Terrain Dissection Raster Grid

Now, you will create a terrain dissection grid. Terrain dissection is a measure of how incised the landscape is at the cell location. This will involve multiple steps. Note that this measure is dependent on the window size specified.

First, you will need to find the maximum elevation value in a circular radius of 9 cells around each cell.

- ☐ Navigate to Spatial Analyst Tools followed by the Neighborhood sub toolbox.
- ☐ Click on the **Focal Statistics Tool**.
- ☐ Set the Input Raster to the **dem** layer.
- ☐ Name the Output Raster **max**.
- ☐ Define the Neighborhood using a "Circle" with a radius of 9 cells.
- ☐ Make sure the Statistic Type is set to "Maximum."
- ☐ You do not need to change any additional settings.
- ☐ Click Run to execute the tool. The output should automatically be added to your map.




You will now need to find the minimum elevation value in a circular radius of 9 cells around each cell.

- Use the methods outlined above to calculate the minimum elevation value in a circular window with a radius of 9 cells. Make sure to use the minimum statistic. Name the output **min**.

Now, you will calculate dissection with the following equation using the **Raster Calculator Tool**:

$$(dem - min) / (max - min)$$

- Navigate to Spatial Analyst Tools followed by the Map Algebra sub toolbox.
- Click on the **Raster Calculator Tool**.
- Define the syntax as follows: ("dem" - "min") / ("max" - "min").
- Name the Output Raster **diss1**.
- You do not need to change any additional settings.
- Click Run to execute the tool. The output should automatically be added to your map.





Just in case one of the cells had a denominator of zero in this calculation, you will need to execute one more step using a conditional statement:

`Con(("max" - "min") == 0, 0, "diss1")`

Here is an interpretation of this conditional statement. If the difference between the **max** and **min** raster grids is zero, then code the result as zero. If it is not, then use the value from the **diss1** grid.

- ☐ Navigate to Spatial Analyst Tools followed by the Map Algebra sub toolbox.
- ☐ Click on the **Raster Calculator Tool**.
- ☐ Define the syntax as follows: `Con(("max" - "min") == 0, 0, "diss1")`. The Con function is available in the tools list.
- ☐ Name the Output Raster **diss2**.
- ☐ You do not need to change any additional settings.
- ☐ Click Run to execute the tool. The output should automatically be added to your map.



Use the output to answer the following question.

Question 10. In terms of topographic dissection, what do low values indicate? (4 Points)


Step 8. Investigating Terrain Change using Multitemporal DEMs

You will now use two DEMs created for the same area but on different dates to explore terrain changes resulting from mining. You will begin by subtracting the surfaces using the **Raster Calculator Tool**.

Before you can start, you will need to do some preparation.

- ☐ Navigate to the Part2 map.
- ☐ Change the environment settings so that the extent, mask, and snap raster are specified relative to the **dem_pre** layer. Change the Cell Size to be the same as the **dem_pre** layer (this should be 9, meaning 9 by 9 meters). Save the environment settings.
- ☐ Create hillshade images from the pre and post surfaces.


If you explore the created hillshade surfaces, you should be able to see terrain change resulting from surface mining.




You are now ready to perform the subtraction.

- ☐ Navigate to Spatial Analyst Tools followed by the Map Algebra sub toolbox.
- ☐ Click on the **Raster Calculator Tool**.
- ☐ Define the syntax as follows: "dem_post" - "dem_pre".
- ☐ You do not need to change any additional settings.

- Click Run to execute the tool. The output should automatically be added to your map.



Question 11. In this model, do negative values indicate elevation gain or elevation loss? (2 Points)



You will now generate a classification of the terrain change using the **Reclassify Tool**. In this model, we will assume that changes of less than 4 meters represent no change (e.g. background noise).

First, change the **symbology** of the change layer to the values that will be used in the reclassification.

- ☐ Right-click on the **change** layer in the Contents Pane then select Symbology. This will open the Symbology Pane.
- ☐ Change the Symbology to classify.
- ☐ Change the Method to Manual and the Classes to 3.
- ☐ Change the upper value for the lower class to -4. Change the upper value for the middle class to 4. Leave the value for the last class.
- ☐ Accept the new symbology.


You are now ready to reclassify the **change** layer using the **Reclassify Tool**.

- ☐ Navigate to Spatial Analyst Tools followed by the Reclass sub toolbox.
- ☐ Click on the **Reclassify Tool**.
- ☐ Set the Input Raster to the **change** layer.
- ☐ Make sure the Reclass Field is set to "Value."
- ☐ Make sure the new values are set to 1, 2, and 3 (this should be the default).
- ☐ Name the Output Raster **chnг_class**.
- ☐ Click Run to execute the tool. The output should automatically be added to your map.

The screenshot shows the 'Reclassify' tool in the Geoprocessing pane. The 'Parameters' tab is active. The 'Input raster' is set to 'change'. The 'Reclass field' is set to 'Value'. The 'Reclassification' table is displayed with the following data:

Start	End	New
-115.254456	-4	1
-4	4	2
4	124.364807	3
NODATA	NODATA	NODATA

Below the table, the 'Output raster' is set to 'chnг_class'. The 'Change missing values to NoData' checkbox is unchecked.



Use the attribute table for the results to answer the following question.

Question 12. What is the total acreage of positive elevation change in this area in acres? (2 Points)

Deliverable 1 (20 Points)


Lastly, create a map of your terrain change output. Submit it as a PDF. This will be worth 20 points and will be graded as follows:

1. Your name is displayed (1 Point)
2. An appropriate scale bar and north arrow are provided (1 Points)
3. An appropriate title is provided (1 Point)
4. The post-mining hillshade is used as the background layer in the map (3 Points)
5. The elevation change classification is correct and shows that the class representing an increase in elevation is labeled as "Fill" and the class representing a decrease in elevation is labeled as "Excavation" (6 Points)
6. The class representing no change should be removed from the legend. Do this by accessing the Symbology Pane for the layer. You can then right-click on the middle legend classifications to remove it. Use the Remove option (3 Points)
7. Appropriate colors are used (1 Point)

8. The change image is displayed with a slight transparency so that the hillshade is visible beneath it (2 Points)
9. The legend shows only the change raster and not the hillshade (2 Points)

Extra: Step 9. Make a Raster Layer Stack

If you want to combine your raster outputs into a multiband or multilayer raster stack, this can be accomplished using the **Composite Bands Tool**, which is in the Raster Processing sub toolbox within the Raster sub toolbox within the Data Management Toolbox. This tool requires that you provide a list of raster grids and name the output.



Extra: Step 10. Convert Raster Grid to Polygons

You can also convert your output to polygons. This can be accomplished using the **Raster to Polygon Tool** in the From Raster sub toolbox in the Conversion Toolbox. For example, this could be used to convert the cut and fill extents created in this lab to polygons.

END OF EXERCISE